

	Main	Tracer	Main Functions
B	Black		**All earth connections, Ground ALWAYS!**
Br	Black	Red	Headlamp relays to headlamp microswitch
U	Blue		Control box to headlamp relays
Ub	Blue	Black	High beam - headlamp dip switch to high beam relay
Un	Blue	Brown	Low beam - headlamp dip switch to low beam relay
Ug	Blue	Green	Headlamp dip switch to high beam indicator light
Ulg	Blue	Lt Green	Windscreen wiper switch to wiper motor
Up	Blue	Purple	Headlamp switch to headlamp dip switch (high/low) Headlamp flasher unit to headlamp flasher microswitch
Ur	Blue	Red	Low beam - headlamp relay to light
Uw	Blue	White	High beam - headlamp relay to light
Uy	Blue	Yellow	Headlamp switch to headlamp flasher relay
N	Brown		**Hot all time, unfused.** Main battery lead, control box to solenoid & courtesy lights, ignition switch (P1) to window switches, and hazard flasher unit
Nu	Brown	Blue	Control box to ignition switch (P1) and light switch (feed)
Ng	Brown	Green	Window switches to window motors. Dynamo to control box
Nlg	Brown	Lt green	Windscreen wiper switch to wiper motor
Nr	Brown	Red	Window switches to window motors
Ny	Brown	Yellow	Dynamo to control box to ignition warning light
G	Green		**Hot with ignition on, fused.** Accessories fused via ignition switch. Fuse box to reverse switch, Wiper motor. Heater fan switch. Washer switch (connects to White Light Green). Indicator flasher unit. Brake failure warning light. Handbrake switch. Brake lights switch. Voltage stabiliser to fuel gauge. Hazard switch to Indicator switch. Ignition switch (pos 4) to radio.
Gb	Green	Black	Fuel gauge to fuel tank sender
Gn	Green	Brown	Reverse switch to reverse lights
Gp	Green	Purple	Brake lamp switch to brake lights. Indicator flasher unit to indicator warning light
Gr	Green	Red	Indicator stalk to left hand indicator
Gw	Green	White	Indicator stalk to right hand indicator
Gy	Green	Yellow	Heater motor switch to heater motor

	Main	Tracer	Main Functions
Lg	Lt Green		Hazard flasher switch to hazard flasher unit
Lgb	Lt Green	Black	Windscreen washer switch to washer pump
Lgn	Lt Green	Brown	Indicator switch to indicator flasher unit
Lgg	Lt Green	Green	Handbrake switch to handbrake warning light
Lgy	Lt Green	Yellow	Hazard flasher unit to hazard warning light
P	Purple		**Hot all time, fused accessories fed directly from battery via fuse box.** Horn. Cirar lighter
Pb	Purple	Black	Horn push to horn. Anti theft switch to horn
Pw	Purple	White	Courtesy light dash switch and door switches to courtesy light
R	Red		Main feed to all running lights mastered by sidelight switch. Sidelights & number plate lights
R	Red	Black	Control box to ignition switch (P1) and light switch (feed)
Rlg	Red	Lt green	Windscreen wiper switch to wiper motor
Rw	Red	White	Dash lights, panel switch to cigar lighter. Window switch power lead to dash courtesy light
W	White		**Hot with ignition on, unfused.** Ignition switch (pos 2) Fuse box. Anti theft switch. Fuse box. Coil. Ignition warning light. High beam warning light
Wu	White	Blue	Headlight flasher relay to high beam headlight curcuit
Wr	White	Red	Ignition switch (pos 3) to starter solenoid
Wp	White	Purple	Ignition switch (pos 4) to fuse box
Wlg	White	Lt green	Windscreen wiper switch to wiper motor
Wb	White	Black	Ignition coil to distributor
Yu	Yellow	Blue	Headlight flasher relay to headlight flasher unit