



The six key body to chassis attachment points shown above are common to both stressed skin and spaceframe chassis.

7/16" U.N.F. tapped holes in rear turrets
- use 9.8 or 9.9 mm or 25/64" drill.

3/8" U.N.F. tapped holes in engine bay and front
section - use 8.4 or 8.5 mm or 21/62" drill.

There are a total of 16 body to chassis attachment points including the six mentioned above.