

body aperture and the screen (if being replaced). If the screen has been broken it is imperative that all granules and splinters of glass are removed from the weatherstrip.

2. Using Bostik '692' sealer, apply a continuous strip to the flange of the body aperture and to the face of the weatherstrip which is in contact with the screen. Fit the weatherstrip to the body aperture.
3. Lay the rear screen on the weatherstrip and starting from a lower corner, lift the lip of the rubber over the edge of the screen with the aid of a small screwdriver (or similar tool) from which all sharp edges have been removed.
4. Using the tool illustrated (see Fig.16) insert the filler strip into the weatherstrip starting at the lower centre.

#### B.24 - HEADLINING.

##### To Remove.

1. Remove the windscreen (Section 'B.22').
2. Remove the rear screen (Section 'B.23').
3. Remove the sun visors by releasing their securing screws.
4. Remove the interior lamps (see Section 'M').
5. Remove the door weatherseal by pulling from its location, the weatherseal being retained by 'built-in' clips.
6. Remove the rear seat backrest (Section 'B.26') and the rear quarter trim (Section 'B.27').
7. The headlining is removed in the following manner:-
  - a. Gently unstick the lining from the windscreen, rear screen and door apertures. Ease the lining free.
  - b. Remove the listing tubes, starting from the front, by springing in their ends. Take care at all times not to stretch the lining excessively, otherwise creases will form during refitting which will be difficult to remove.

##### To Replace.

Replacement is a reversal of the removal procedure, but attention must be given to the following points:-

1. Start fitting the listing tubes from the rear.
2. With all the listing tubes located, coat the body flanges to which the lining is attached and the inside edge of the lining with Dunlop 'S.758' adhesive. Allow 10 - 15 minutes for the adhesive to become tacky, then commence sticking down the headlining, working from the centre outwards.
3. Stick the lining carefully, taking out all creases and bulges, both in the lining and in the edges. If the lining is only partially removed and turned back, roll it carefully and do not fold or crease the material. Refit, if