

Fig. 57 R.H.D. Facia panel and controls (Special Equipment)




Fig. 58 R.H.D. Facia panel and controls ('S' model)




Fig. 59 L.H.D. Facia panel and controls (USA Federal)

Key.

- | | |
|---|--|
| 1. Ventilators. | 27. Ashtray. |
| 2. Steering wheel. | 28. Ignition/starter switch. |
| 3. Warning lamp. | 29. Headlamp Vacuum control. |
| 4. Speedometer. | 30. Clutch pedal. |
| 5. Warning lamp direction indicator. | 31. Brake pedal. |
| 6. Warning lamp handbrake. | 32. Accelerator pedal. |
| 7. Warning lamp headlamp main beam. | 33. Handbrake. |
| 8. Tachometer. | 34. Bonnet (hood) release. |
| 9. Warning lamp. ignition. | 35. Combined direction indicator, horn & headlamp control. |
| 10. Oil pressure gauge. | 36. Trip reset. |
| 11. Panel lamp switch. | 37. Water temperature gauge. |
| 12. Wiper/washer control. | 38. Choke control. |
| 13. Combined side, rear & headlight switch. | 39. Direction indicator switch. |
| 14. Crash pad. | 40. Headlamp dip switch. |
| 15. Heater controls. | 41. Warning lamp for 45. |
| 16. Heater controls. | 42. Brake fail warning lamp. |
| 17. Radio. | 43. Warning lamp for 44. |
| 18. Heater fan switch. | 44. Rear screen heater switch. |
| 19. Cigar lighter. | 45. Hazard warning switch. |
| 20. Interior lamp switch. | 46. Test switch for 42. |
| 21. Demist grille. | 47. Auxiliary driving lamp. |
| 22. Fuel gauge. | 48. Auxiliary driving lamp. |
| 23. Ammeter. | 49. Clock. |
| 24. Glove box. | 50. Clock handset. |
| 25. Gear lever. | 51. Outside temperature gauge. |
| 26. Window switches. | 52. Map lamp. |