

Action With the boot lid in the fully open position, ensure that the ramp of the actuating bracket (which operates the switch), is uppermost as shown in the illustration.

If the bracket is mounted as shown 'dotted' in the illustration, then the lamp will be permanently illuminated, therefore, remove and re-fit bracket in -its correct position.

Finally, check that the lamp is being extinguished by the operation of the actuating bracket upon the switch, which should occur BEFORE the boot lid engages its switch.

