

2. From behind the facia panel attach the tubing to the ventilator body and secure with adhesive tape.

P. 3 - VENTILATOR TUBES.

To Remove.

1. Remove the face level ventilators (Section 'P.2').
2. Remove the facia panel (see Section 'B').
3. Remove the adhesive tape securing the ventilator tubes to the heater unit and release tubes.

To Replace.

1. Push the ventilator tubes onto the heater unit and secure with adhesive tape.
2. Replace the facia panel.
3. Replace the face level ventilators.

P. 4 - DEMISTER TUBES AND NOZZLES.

To Remove.

1. Remove the facia panel (see Section 'B').
2. Remove the adhesive tape securing the tubes to both the heater unit and the nozzles. On some cars, the demist tubes may be in a pre-formed elbow shape.
3. The demist nozzles are removed by extracting the screws securing the demist grilles to the crash pad, these screws also securing the nozzles.

To Replace.

1. Secure the demist nozzles in their locations with the screws which also retain the demist grilles. Note that the nozzles are handed when refitting.
2. Push the tubes onto both the heater unit and the demist nozzles, securing with adhesive tape.
3. Replace the facia panel.

P. 5 - HEATER CONTROLS.

To Adjust.

1. Remove the facia panel (Section 'B').