

ELAN Plus 2 1968 / 1969 GENERAL WIRING COLOUR LIST

Temperature Gauge –

Green/Blue from engine temperature sender

Green from voltage stabilizer

Green to fuel gauge

Black - Earth

Red/White – gauge light

Fuel Gauge –

Green from temperature gauge

Green/Black to fuel tank sender via bulkhead connector

Black - Earth

Red/white – gauge light

Amp Meter Gauge –

Brown to starter solenoid via bulkhead connector

Brown/White to control box

Black – Earth

Red/White – gauge light

Oil Pressure Gauge –

White/Brown from pressure switch via bulkhead connector (if electric)

Black – Earth

Red/White – gauge light

Ignition Switch –

1 - Brown/Blue from control box via bulkhead connector

1 – Brown/Blue to lights switch

4 – Green Aux to Radio

3 – White/Red to starter solenoid via bulkhead connector

20 – Red/Green to voltage stabilizer -/- Red/Green to Tachometer + coil (via anti-theft switch)

Column Switch –

Purple/Black to horn relay via bulkhead connector

Brown/Blue to 6RA headlamp relay

Blue/White to main beam headlight flasher unit via bulkhead connector / Blue/White to high beam warning light in tachometer

Blue/Red to dip beam headlights via bulkhead connector

Brown/Green from indicator flasher unit

Green/Red to left indicator via bulkhead connector

Green/White to right indicator via bulkhead connector

Wiper/ Wash Switch –

Light Green to wiper control 3 via bulkhead connector

Yellow to wiper control 5 via bulkhead connector

Blue/Yellow to wiper control 2 via bulkhead connector

Green to Indicator flasher unit (Green also to Oil gauge, if electric and HRW switch if fitted)

[At wiper control – Green (4) is from fuse box. Earth is (1)]

Lights Switch –

Brown/Blue from ignition switch

Blue/Black to headlamp flasher relay via bulkhead connector

Blue to 6RA flasher relay

Red to panel switch & to front/rear sidelights/number plate lights via bulkhead connector

Panel Switch –

Red from Light Switch

Red/White to gauge lights

Heater Switch –

Green from fuse box via bulkhead connector & Green to indicator flasher unit

Red/Brown to heater

Brown/White to heater

Interior Switch –

Black – Earth

Purple/White to door switches / Interior light / rear lights via bulkhead connector

Window Switches x 2 –

Purple to other window switch

Blue/Yellow to window motor

Black/Blue to window motor

Indicator Flasher Unit –

Green from heater switch/wiper switch

Green/Purple to indicator light in speedometer

Brown/Green to indicator switch

Headlight Flasher (6RA) –

Brown/Purple to Headlamp micro switch via bulkhead connector

Brown/Blue to column switch

Blue to lights switch

Anti-Theft Switch –

Red/Green to tachometer

Red/Green from ignition switch (20)

Reverse Switch (At Gearbox) –

Green from fuse box

Green/Brown to reverse lights via bulkhead connector

Handbrake switch –

Green from wash/wipe switch

Green to warning light (black from light to earth)

Brake (Stop) switch –

Green from fuse box

Green/Purple to stop lights

Coil –

Red/Green to tachometer

White/Black to distributor

Cigar Lighter –

Purple

Black – Earth

Horn Relay –

Purple/White from fuse box

Purple/Black from horn push

Light green to horn compressor

Fuel Tank Sender Unit –

Green/Brown to fuel gauge via bulkhead connector

Black/Brown to speedometer warning light via bulkhead connector

Black - Earth

Tachometer –

Red/Green to coil & Red/Green to Anti-theft switch then to Ignition switch

Blue/white from column switch - full beam warning light

Black – Earth -/- Red/White – instrument light

Speedometer –

Black/Brown from fuel sender - low fuel warning light

Green purple from indicator flasher – indicator flashing light

Black – Earth -/- Red/white – instrument light

